

Aqueous CYAN Update

Topics:

- Dirty Air Stone
- Homemade EC probe
- Another Cyan run using EC probe


David Wilson
dw@ieee.org

August 2, 2021

Aqueous CYAN Basics

(Updated from July 9 Report)

- Same reaction as Classic CYAN:
 $\text{Ca(OH)}_2 + \text{CO}_2 \rightarrow \text{CaCO}_3 + \text{H}_2\text{O}$
- Parts reuse: Aquarium pump, air stone, chemicals, soda bottle
- Newer: Electrical Conductivity (EC) Monitoring



New Issue: Dirty Air Stone


OLD

NEW



OLD



NEW



EC Measurement

<https://hackaday.io/project/7008-fly-wars-a-hackers-solution-to-world-hunger/log/24646-three-dollar-ec-ppm-meter-arduino>

- Probe: 2 wires, 2 buttons
- Circuit: voltage divider and uC
- PULSED measurement required
- OMIT temperature adjustment



Han's Paper

Carbon Dioxide Capture Using Calcium Hydroxide Aqueous Solution as the Absorbent

Sang-Jun Han, Miran Yoo, Dong-Woo Kim, and Jung-Ho Wee*

Department of Environmental Engineering, The Catholic University of Korea, 43-1, Yeokgok 2-dong, Wonmi-gu, Bucheon-si, Gyeonggi-do 420-743, Republic of Korea




Figure 1. Schematic diagram for a CO₂-capture system using Ca(OH)₂ aqueous solution as the absorbent: (1) N₂ cylinder, (2) CO₂ cylinder, (3) MFC, (4) gas mixer, (5) temperature controller, (6) Pyrex reactor, (7) sparger, (8) magnetic stirrer, (9) thermometer, (10) pH sensor, (11) EC sensor, (12) pH/EC meter, (13) dehumidifier, (14) sampling pump, (15) gas analyzer, and (16) computer for data acquisition.





Figure 11. CO₂-capture efficiencies of each absorbent in the pH ranges.

Han Paper Detail

Saturated $\text{Ca}(\text{OH})_2$ solution



Newest Experiment


- 1g Ca(OH)_2 in 1L water. Solubility of Ca(OH)_2 in H_2O : 1.73 g/L at 20C. [Same as last week]
- Calibration of EC probe: estimate 8000uS/cm (*) in our solution
- Pumped air through air stone (bubbler), while measuring EC every 30 seconds.
- Periodically measured pH (with paper).
- Kept going until EC and pH flattened out

•Note on units: S \equiv Siemens \equiv mho \equiv 1/ohm

•It is /cm because it's a spatially distributed resistance

Results

Ca(OH)₂ Aqueous Cyan



For Followup

- Understand overshoot in EC at start.
- Better air stone (sparger) needed? Or keep, but clean or dispose.
- Ideas for automating end of process:
 - Electronic pH meter (\$\$)
 - Electronic resistivity measurement (\$)
- Need to pump more air
- Distilled water? Purer sorbent?
- How to separate and dry precipitate?