

Aqueous CYAN Update


David Wilson
dw@ieee.org

July 26, 2021

Aqueous CYAN Basics

(Updated from July 9 Report)

- Same reaction as Classic CYAN:
 $\text{Ca(OH)}_2 + \text{CO}_2 \rightarrow \text{CaCO}_3 + \text{H}_2\text{O}$
- Parts reuse: Aquarium pump, air stone, chemicals. **New: replace plastic box with 1-L soda bottle.**



Han's Paper

Carbon Dioxide Capture Using Calcium Hydroxide Aqueous Solution as the Absorbent

Sang-Jun Han, Miran Yoo, Dong-Woo Kim, and Jung-Ho Wee*

Department of Environmental Engineering, The Catholic University of Korea, 43-1, Yeokgok 2-dong, Wonmi-gu, Bucheon-si, Gyeonggi-do 420-743, Republic of Korea




Figure 1. Schematic diagram for a CO₂-capture system using Ca(OH)₂ aqueous solution as the absorbent: (1) N₂ cylinder, (2) CO₂ cylinder, (3) MFC, (4) gas mixer, (5) temperature controller, (6) Pyrex reactor, (7) sparger, (8) magnetic stirrer, (9) thermometer, (10) pH sensor, (11) EC sensor, (12) pH/EC meter, (13) dehumidifier, (14) sampling pump, (15) gas analyzer, and (16) computer for data acquisition.





Figure 11. CO₂-capture efficiencies of each absorbent in the pH ranges.

Main Take-aways (for me) from Han's Paper

- When pH goes < 10 as CO_2 is captured, CaCO_3 (precipitate) production STOPS.
- As pH continues to drop, CaCO_3 combines with more CO_2 to produce (soluble!) HCO_3^- ions...
- ...until by the time pH < 7 , there's no more CaCO_3 precipitate.
- We should stop when pH reaches 10, so we can recover solid output, and
- Most CO_2 has already been captured.

Han Paper Detail


Saturated $\text{Ca}(\text{OH})_2$ solution



My Experiment

- 1g Ca(OH)_2 in 1L water. Solubility of Ca(OH)_2 in H_2O : 1.73 g/L at 20C.
- Pumped air through air stone (bubbler), periodically checking pH with pH paper.
- Stopped when pH reached 10.

pH vs. Time



Results

- Stopped at 19:44.
- Siphoned out clear solution
- Dried precipitate in air



Analysis

- Weight of dry precipitate: 1.044g
- Vinegar test: significant bubbling!
- Calculated CO₂ captured: 0.459g (from 1g input material—77% of theoretical)



Followup

- **Caveat:** calculated capture amount may be over-estimate due to impurities in water and sorbent.
- Ideas for automating end of process:
 - Electronic pH meter (\$\$)
 - Electronic resistivity measurement (\$)
- Need to pump more air
- How to separate and dry precipitate?