

Aqueous CYAN Update

Topics:

- New pH probe!
- Aqueous run with pH and EC
- Scaling up?

David Wilson
dw@ieee.org

September 13, 2021

Aqueous CYAN Basics


- Same reaction as Classic CYAN:
 $\text{Ca(OH)}_2 + \text{CO}_2 \rightarrow \text{CaCO}_3 + \text{H}_2\text{O}$
- Parts reuse: Aquarium pump, air stone, chemicals, soda bottle
- **Newer: Electrical Conductivity (EC) Monitoring**
- *Even newer: pH meter*



EC Measurement

<https://hackaday.io/project/7008-fly-wars-a-hackers-solution-to-world-hunger/log/24646-three-dollar-ec-ppm-meter-arduino>

- Probe: 2 wires, 2 buttons
- Circuit: voltage divider and uC
- PULSED measurement required
- OMIT temperature adjustment
- Note: EC probe interferes with pH measurement, so had to isolate (not shown)



Han's Paper

Carbon Dioxide Capture Using Calcium Hydroxide Aqueous Solution as the Absorbent

Sang-Jun Han, Miran Yoo, Dong-Woo Kim, and Jung-Ho Wee*

Department of Environmental Engineering, The Catholic University of Korea, 43-1, Yeokgok 2-dong, Wonmi-gu, Bucheon-si, Gyeonggi-do 420-743, Republic of Korea




Figure 1. Schematic diagram for a CO₂-capture system using Ca(OH)₂ aqueous solution as the absorbent: (1) N₂ cylinder, (2) CO₂ cylinder, (3) MFC, (4) gas mixer, (5) temperature controller, (6) Pyrex reactor, (7) sparger, (8) magnetic stirrer, (9) thermometer, (10) pH sensor, (11) EC sensor, (12) pH/EC meter, (13) dehumidifier, (14) sampling pump, (15) gas analyzer, and (16) computer for data acquisition.





Figure 11. CO₂-capture efficiencies of each absorbent in the pH ranges.

Han Paper Detail

Saturated $\text{Ca}(\text{OH})_2$ solution




Newest Experiment: Now with pH Meter

- 1g Ca(OH)_2 in 1L water. Solubility of Ca(OH)_2 in H_2O : 1.73 g/L at 20C. [Same as last time]
- Calibration of EC probe: estimate 8000uS/cm (*) in our solution
- Pumped air through air stone (bubbler), while measuring EC every 30 seconds.
- Also measured pH (*with meter*).
- Kept going until EC and pH flattened out
- Used distilled water this time: no initial sediment


- Note on units: $\text{S} \equiv \text{Siemens} \equiv \text{mho} \equiv 1/\text{ohm}$
- It is /cm because it's a spatially distributed resistance

Results (1g/L)




What if we take \log_{10} of EC?

(and shift to line up with pH)



Scaling up: 10g/L Aqueous Test

First run, uninterrupted



Why?

- Air stone getting clogged before run finishes
- Air stone not resting on bottom, so sediment+input material not getting stirred up



Continuing Issue: Dirty Air Stone


OLD

NEW



OLD

NEW




Attempted remedies

- Clean air stone
- Shake bottle thoroughly to stir up sediment
- Make sure air stone rests on *bottom* of bottle to stir up sediment

Scaling up: 10g/L Aqueous Test

CONTINUED after remedies



After 10g run...



For Followup

- Better aerator (sparger) needed?
- Understand pH vs. EC
- Need to pump more air
- How to separate and dry precipitate?
- Weigh precipitates from both runs and calculate amount of CO₂ captured